Children intelligent bracelet

Description:

Children intelligent bracelet , using dual positioning technology , compact , portable, long standby time. Simple to use for child care . Location information can be found by three kinds of methods (phone , SMS , Internet) .

二、Accessories：

Item	Quantity
Children intelligent bracelet	1
USB cable	1
Charger	1
User manual	1

三、Product Features:

1. **GPS+LBS** Dual positioning
2. Multiple base stations precise positioning
3. Locus playback

4.Parent-child interaction
with red flower
5. Low battery alert.
6. Moving Detection
7. Multiple operating modes
8. Lower radiation , long standby time
9. LED clock display , adjust the time automatically
10. SOS emergency alarm

四、Operating Instructions :

1. Install the SIM card

Firstly insert Nano SIM card into the slot as directed.

Secure cover back (battery contacts must aim at the shrapnel of circuit board) use the screws to fix the core.

2. Power on/off

Press the POWER key for 3

sec ,then the bracelet will power on. Rolling bar , pressing the power button once to display the current time after one minute (no need to manually set)

Notice:

When the SIM card installed incorrectly , SIM card is in arrears

status or SIM card has expired , the upper left corner of the little hearts will light up . Please check the SIM immediately if there is upside inserted .

3.Check the status of red flowers

In the state of display time, press the button shortly, bracelet will show the red flower’s quantities.

4. Emergency alarm

Press the POWER key for 3 sec to enter emergency alarm status, bracelet shows 4 hyphens,

activating emergency alarm, bracelet will send a sos help SMS and make a sos help call to preset emergency number. GPS start. After the exact location of GPS, bracelet will send exact location to the emergency number.

5. Low battery alarm

When the battery is below 30% of total electricity consumption, bracelet will send reminder message to preset emergency number.

6.Display the battery when charging

Press the power key to

display the battery in charging as

soon as connected to the charger even it’s power on/off. When the battery is 100% full ,please keep charging for 30 minutes to ensure enough full.

五、Voice Control:

Note: The preset password is 123456

Use the SOS number to dial the SIM card number of device , you will

enter the voice monitoring state and you can hear instruction like this:
For voice monitoring, press 1,
To track location message, press 2,
-Hang up the phone, after successful positioning bracelet will send location information to the master number .

六、SMS commands:

Command	Function
123	Check the position

456	Check the battery , set the parameters
999	set time interval to open and dwell period .
LBS	Check approximate position

七、Phone monitoring software:

1. Android users:
Scanning dimensional code in manual’s home page to download.

2.Use cellphone to access website, download the app in login page.

3.Iphone user:

Download the app from the APP Store.

1、Login：

User name: the code in the back of bracelet.

Preset password：123456

2、Real Time Location：

You can see the real-time location after login, please click the circle marked places when you login first time.

3、Setting for the first time use

bracelet

Input the sim card number into ” Device card number” and change the device name as you like. Click ” modification” .

4、Monitoring Interface

Introduction:

Click " accurate positioning

",bracelet will open GPS,this function will curtail standby time, please do not use unless necessary.

5、Setting bracelet parameter

Please follow the instruction of APK/APP to set.

Common Problems and behaviour

1.SIM card incorrectly installed, Bad card and non-card: It will not display the correct time after boot for a long time , dial SIM card number will prompt off.

2. SIM card arrears down: Since the operator stop the GPRS function, APK/APP will offline for long time.

3.GPS difficult to locate: GPS signal not good or no signal that will difficult to locate the precise position .

4. The backend server shows

inaccurate location:

In normal working condition, use LBS positioning, position deviation at this time will be around 1-300 meters. If you need positioning accurately, please open GPS by SMS or voice control.

Warranty scope:

1) The product due to material reasons cause

damage need to replace parts for non-human damage.

2) The products malfunction under normal use.

3) Please keep warranty card safely for after-sale service, as well as your receipt.